

How do I choose a bearing?

Our company offers different How do I choose a bearing? at Wholesale Price? Here, you can get high quality and high efficient How do I choose a bearing?

A Guide to Selecting the Correct Bearing Feb 14, 2019 — With dozens of types of bearings and hundreds of thousands to choose from, selecting the correct bearing for your application can be a

How to Determine Bearing Types Jun 19, 2017 — With the variety of high-specialized bearing options, it can be daunting just to decide where to begin. May we suggest this article as a starting How to Select the Right Bearing (Part 1): The order of priority Jan 30, 2020 — 1. What are the criteria for selecting bearings? · Criterion 1: It should be appropriate for the machine's usage environment and the operating

Choosing the Right Bearing |. Designers choosing a standard bearing type should take a close look at the available design envelope; loads (magnitude and direction); potential misalignment;

9 Keys of How to Choose Proper Type of Bearing for Your Allow space of various type of bearing. Bearing load. The load size is usually the determinant of the bearing size. Bearing speed. The working speed of the rolling bearing mainly depends on the allowable operating temperature. Rotation accuracy. Rigidity. Noise and vibration. The axial moving. Friction torque Choosing the right bearing - Buying Guides Direct Industry When choosing a bearing, you must consider several important factors. The first factor to consider is the load that the bearing can support. Each type of bearing is specifically designed to support an axial or radial load. Some bearings can support both loads: in this case we refer to a combined load

SUPER PRECISION BEARINGS			
NTN Bearing	KOYO Bearing	NSK Bearing	NACHI Bearing
5S-BNT0	5S-2LA-HSE011C	7926U	BNH007
329	5S-2LA-HSE034C	7000UC	BNH024
BNT2/5S-BNT2	5S-2LA-HSE030	7016UC	BNH026
7826CT1	5S-2LA-HSE026AD	7017UC	35TAB07-2NKE
BSB 035072	2LA-HSL911UC	7001UAD	35TAB07-2NSE
BSB 100150	2LA-HSL913U	7002UAD	60TAB12-2NSE
7910A5TRSU	2LA-HSL915UAD	7018UAD	25TAF05X
7919CTRSU	2LA-HSL017C	7019UAD	120TAF26X
7932A5TRSU	2LA-HSL019	7010U	7000W1YDFNSE9
7000CTRSU	2LA-HSL021AD	7011U	7004W1YDFNKE9
7008A5TRSU	5S-2LA-HSL924UC	5S-7911UC	7005W1YDFNKE9
7017CTRSU	5S-2LA-HSL910UAD	5S-7912UC	25TAB06DF?DB?-2NK
7028A5TRSU	5S-2LA-HSL012C	5S-7903UAD	30TAB06DF?DB?-2NK
7202CTRSU	5S-2LA-HSL014	5S-7904UAD	60TAB12DF?DB?

7210A5TRSU	5S-2LA-HSL016AD	5S-7920UAD	BST17X47-1B
7219CTRSU	5S-2LA-HSFL018AD	5S-7921UAD	60TAU14F
MMF515BS60PP DM	7903ADLLB	5S-7912U	BNH021
MMN540BS75PP DM	7009CDLLB	5S-7913U	30TAB06-2NKE
MM40BS72	5S-7904CDLLB	5S-7004UC	55TAB12-2NSE
MM9321WI3	5S-7910ADLLB	5S-7005UC	100TAF21X
25TAU07F	5S-7005ADLLB	5S-7021UC	7002W1YDFNKE9
7003W1Y	2LA-BNS910LLB	5S-7022UC	17TAB04DF?DB?-2NK
BNH013	2LA-BNS916ADLLB	5S-7013UAD	55TAB10DF?DB?
15TAB04-2NKE	2LA-BNS009LLB	5S-7014UAD	BST55X120-1B
45TAB07-2NSE	2LA-BNS014ADLLB	5S-7005U	7908UC
45TAF10X	5S-2LA-BNS920CLLB	5S-7006U	7928CT1B
7200W1YDFNSE9	5S-2LA-BNS014CLLB	5S-7022U	7913UAD
7205W1YDFNKE9	5S-2LA-BNS019LLB	5S-7024U	7905U
25TAB06DF?DB?	BNT903	2LA-HSE926UC	7922U
BST35X72-1B	5S-BNT908	2LA-HSE928UC	7014UC
7900UC	5S-BNT011	2LA-HSE922U	7040CT1B
7917UC	5S-BNT213	2LA-HSE924U	7016UAD
7905UAD	5S-2LA-HSFL0	2LA-HSE920UAD	7008U
7922UAD	5629 (M)	2LA-HSE921UAD	5S-7909UC
7914U	2LA-HSE9/5S-2LA-HSE9	2LA-HSE018C	5S-7901UAD
7006UC	HTA0A/5S-HTA0A	2LA-HSE019C	5S-7918UAD
7024UC	BSB 2025	2LA-HSE016	5S-7910U
7008UAD	BSB 225	2LA-HSE017	5S-7002UC
7000U	7908A5TRSU	2LA-HSE014AD	5S-7019UC
7017U	7917CTRSU	2LA-HSE015AD	5S-7011UAD
5S-7901UC	7928A5TRSU	5S-2LA-HSE912UC	5S-7003U
5S-7918UC	7952CTRSU	5S-2LA-HSE913UC	5S-7020U
5S-7910UAD	7006A5TRSU	5S-2LA-HSE910U	2LA-HSE922UC
5S-7902U	7015CTRSU	5S-2LA-HSE911U	2LA-HSE920U
5S-7919U	7024A5TRSU	5S-2LA-HSE932U	2LA-HSE918UAD
5S-7011UC	7200CTRSU	5S-2LA-HSE934U	2LA-HSE016C
5S-7003UAD	7208A5TRSU	5S-2LA-HSE928UAD	2LA-HSE014
5S-7020UAD	7217CTRSU	5S-2LA-HSE930UAD	2LA-HSE012AD
5S-7012U	7228A5TRSU	5S-2LA-HSE024C	5S-2LA-HSE910UC
2LA-HSE914UC	MMN520BS52PP DM	5S-2LA-HSE026C	5S-2LA-HSE932UC
2LA-HSE912U	MM30BS72	5S-2LA-HSE021	5S-2LA-HSE928U
2LA-HSE910UAD	MM60BS120	5S-2LA-HSE022	5S-2LA-HSE924UAD
2LA-HSE932UAD	BS55/120	5S-2LA-HSE019AD	5S-2LA-HSE021C
2LA-HSE028C	7004XYS1	5S-2LA-HSE020AD	5S-2LA-HSE019
2LA-HSE024	BNH009	5S-2LA-HSF017AD	5S-2LA-HSE017AD
2LA-HSE021AD	BNH030	5S-2LA-HSF018AD	5S-2LA-HSF015AD
5S-2LA-HSE919UC	40TAB07-2NSE	2LA-HSL924UC	2LA-HSL921UC
5S-2LA-HSE917U	30TAF07X	2LA-HSL926UC	2LA-HSL924U
5S-2LA-HSE915UAD	7002W1YDFNSE9	2LA-HSL910UAD	2LA-HSL010C

5S-2LA-HSE013C	7201W1YDFNKE9	2LA-HSL911UAD	2LA-HSL012
5S-2LA-HSE011	40TAB07DF?DB?-2NK	2LA-HSL012C	2LA-HSL014AD
5S-2LA-HSE034	BST20X47-2B	2LA-HSL013C	5S-2LA-HSL916UC
5S-2LA-HSE030AD	7913UC	2LA-HSL014	5S-2LA-HSL918U
2LA-HSL913UC	7901UAD	2LA-HSL015	5S-2LA-HSL920UAD
2LA-HSL915U	7918UAD	2LA-HSL016AD	5S-2LA-HSL022C
2LA-HSL917UAD	7910U	2LA-HSL017AD	5S-2LA-HSL026
2LA-HSL019C	7002UC	5S-2LA-HSL918UC	5S-2LA-HSFL011AD
2LA-HSL021	7019UC	5S-2LA-HSL919UC	7907CDLLB
2LA-HSL024AD	7004UAD	5S-2LA-HSL920U	7002CDLLB
5S-2LA-HSL910U	7021UAD	5S-2LA-HSL921U	7008ADLLB
5S-2LA-HSL912UAD	7013U	5S-2LA-HSL922UAD	5S-7903ADLLB
5S-2LA-HSL014C	7222CT1B	5S-2LA-HSL924UAD	5S-7009CDLLB
5S-2LA-HSL016	5S-7914UC	5S-2LA-HSL026C	2LA-BNS914CLLB
5S-2LA-HSL018AD	5S-7906UAD	5S-2LA-HSL010	2LA-BNS920LLB
5S-2LA-HSFL020AD	5S-7924UAD	5S-2LA-HSL011AD	2LA-BNS014CLLB
7905ADLLB	5S-7915U	5S-2LA-HSL012AD	2LA-BNS019LLB
7000ADLLB	5S-7007UC	5S-2LA-HSFL013AD	5S-2LA-BNS913CLLB
5S-7906CDLLB	5S-7026UC	5S-2LA-HSFL014AD	5S-2LA-BNS919LLB
5S-7001CDLLB	5S-7016UAD	7909CDLLB	5S-2LA-BNS012LLB
5S-7007ADLLB	5S-7008U	7910CDLLB	5S-2LA-BNS017ADLLB
2LA-BNS912LLB	2LA-HSE910UC	7004CDLLB	BNT913
2LA-BNS918ADLLB	2LA-HSE932UC	7005CDLLB	5S-BNT901
2LA-BNS011LLB	2LA-HSE928U	7010ADLLB	5S-2LA-HSF0
2LA-BNS016ADLLB	2LA-HSE924UAD	5S-7900CDLLB	NN30HS (K)
5S-2LA-BNS911LLB	2LA-HSE021C	5S-7905ADLLB	ARN
5S-2LA-BNS016CLLB	2LA-HSE019	5S-7906ADLLB	NN30HSRT6/NN30HS RT6K
5S-2LA-BNS009ADLLB	2LA-HSE017AD	5S-7000ADLLB	BSB 175
BNT905	5S-2LA-HSE915UC	5S-7001ADLLB	7905CTRSU
BNT210	5S-2LA-HSE913U	2LA-BNS916CLLB	7913A5TRSU
5S-BNT910	5S-2LA-HSE911UAD	2LA-BNS917CLLB	7922CTRSU
5S-BNT013	5S-2LA-HSE934UAD	2LA-BNS911ADLLB	7938A5TRSU
5S-BNT215	5S-2LA-HSE030C	2LA-BNS912ADLLB	7003CTRSU
5S-2LA-BNS0LLB	5S-2LA-HSE026	2LA-BNS016CLLB	7011A5TRSU
HTA9U	5S-2LA-HSE022AD	2LA-BNS017CLLB	7020CTRSU
BNT9/5S-BNT9	5S-2LA-HSF020AD	2LA-BNS009ADLLB	7034A5TRSU
HTA0U/5S-HTA0	2LA-HSL911U	2LA-BNS010ADLLB	7205CTRSU
BSB 030062	2LA-HSL913UAD	5S-2LA-BNS915CLLB	7213A5TRSU
BSB 075110	2LA-HSL015C	5S-2LA-BNS916CLLB	7222CTRSU
7909A5TRSU	2LA-HSL017	5S-2LA-BNS009CLLB	MMF540BS100PP DM
7918CTRSU	2LA-HSL019AD	5S-2LA-BNS010CLLB	MM17BS47
7930A5TRSU	5S-2LA-HSL921UC	5S-2LA-BNS014LLB	MM45BS75
7956CTRSU	5S-2LA-HSL924U	5S-2LA-BNS015LLB	BS 30/62
7007A5TRSU	5S-2LA-HSL010C	5S-2LA-BNS019ADLLB	7221C
7016CTRSU	5S-2LA-HSL012	5S-2LA-BNS020ADLLB	NN3018

7026A5TRSU	5S-2LA-HSL014AD	5S-BNT903	N1014
7201CTRSU	5S-2LA-HSFL016AD	5S-BNT904	BNT200
7209A5TRSU	7901ADLLB	5S-2LA-HSL9	5S-BNT003
7218CTRSU	7007CDLLB	2LA-HSL0	5S-BNT205
7230A5TRSU	5S-7902CDLLB	NN30HSRT6 (K)	7216C
MMN530BS62PP DM	5S-7908ADLLB	NNU49 (K)	NN3011K
MM35BS100	5S-7003ADLLB	70 LLB/5S-70 LLB	NN3034K
MM9316WI3H	2LA-BNS919CLLB	2LA-BNS9 LLB/5S-2LA-BNS9 LLB	NNU4932K
17TAU06F	2LA-BNS914ADLLB	NNU49/NNU49K	7819C
7001W1Y	2LA-BNS019CLLB	N10HS/N10HSK	NNU4928
BNH011	2LA-BNS012ADLLB	BSB 017047	300XRN40
BNH034	5S-2LA-BNS918CLLB	BSB 045100	7219C
40TAB09-2NSE	5S-2LA-BNS012CLLB	BSB 050090	90TAH10DB
40TAF09X	5S-2LA-BNS017LLB	7906CTRSU	80TBH10DB
7004W1YDFNSE9	BNT901	7906A5TRSU	NN3009
7203W1YDFNKE9	5S-BNT906	7914A5TRSU	NN3030
17TAB04DF?DB?	5S-BNT211	7915CTRSU	7900C
BST25X62-1B	79 LLB	7924CTRSU	7908AC
7915UC	N10HSL (K)	7924A5TRSU	7006C
7903UAD	79U/5S-79U	7940A5TRSU	7014AC
7920UAD	N10HSLT6/N10HSLT6 K	7944CTRSU	7202C
7912U	BSB 078	7004CTRSU	7210AC
7004UC	BSB 055090	7004A5TRSU	ZKLF1560-2RS
7021UC	7907A5TRSU	7012A5TRSU	ZKLN4075-2RS
7006UAD	7916CTRSU	7013CTRSU	40TAB09
7024UAD	7926A5TRSU	7021CTRSU	50TAU14F
7015U	7948CTRSU	7021A5TRSU	BNH020
7226CT1B	7005A5TRSU	7036A5TRSU	25TAB06-2NSE
5S-7916UC	7014CTRSU	7038CTRSU	55TAB12-2NKE
5S-7908UAD	7022A5TRSU	7206CTRSU	80TAF21X
5S-7900U	7040CTRSU	7206A5TRSU	7001W1YDFNKE9
5S-7917U	7207A5TRSU	7214A5TRSU	40TAB09DF?DB?-2LR
5S-7009UC	7216CTRSU	7215CTRSU	50TAB10DF?DB?
5S-7001UAD	7226A5TRSU	7224CTRSU	BST50X100-1B
5S-7018UAD	MMN515BS45PP DM	7224A5TRSU	7907UC
5S-7010U	MM25BS62	MMF550BS140PP DM	7926UC
2LA-HSE912UC	MM55BS120	MMF560BS145PP DM	7912UAD
2LA-HSE910U	BS 45/100	MM9306WI2H	7904U
2LA-HSE932U	7910UC	MM9308WI2H	7921U
2LA-HSE928UAD	7911UC	MM50BS90	7013UC
2LA-HSE024C	7932CT1B	MM50BS100	7038CT1B
2LA-HSE021	7934CT1B	BS 40/72	7015UAD
2LA-HSE019AD	7915UAD	BS 40/90	7007U
5S-2LA-HSE917UC	7916UAD	ZKLN60110-2RS	7026U

5S-2LA-HSE915U	7907U	7001XYS1	5S-7908UC
5S-2LA-HSE913UAD	7908U	7002XYS1	5S-7900UAD
2LA-BNS013CLLB	7011CTRSU	5S-2LA-HSL915UC	5S-7917UAD
2LA-BNS018LLB	7019A5TRSU	5S-2LA-HSL917U	5S-7909U
5S-2LA-BNS912CLLB	7034CTRSU	5S-2LA-HSL919UAD	5S-7001UC
5S-2LA-BNS918LLB	7204A5TRSU	5S-2LA-HSL021C	5S-7018UC
5S-2LA-BNS011LLB	7213CTRSU	5S-2LA-HSL024	5S-7010UAD
5S-2LA-BNS016ADLLB	7221A5TRSU	5S-2LA-HSFL010AD	5S-7002U
BNT912	MMF535BS90PP DM	7906CDLLB	5S-7019U
5S-BNT900	MM15BS35	7001CDLLB	2LA-HSE921UC
5S-2LA-HSE0	MM9311WI3H	7007ADLLB	2LA-HSE919U
NN30 (K)	BS 25/62	5S-7902ADLLB	2LA-HSE917UAD
AXN	5S-2LA-HSE020C	5S-7008CDLLB	2LA-HSE015C
NN30HST6/NN30HST6 K	5S-2LA-HSE018	2LA-BNS913CLLB	2LA-HSE013
BSB 040100	5S-2LA-HSE016AD	2LA-BNS919LLB	2LA-HSE011AD
7904A5TRSU	5S-2LA-HSF014AD	2LA-HSL011	2LA-HSE034AD
7913CTRSU	2LA-HSL920UC	2LA-HSL013AD	5S-2LA-HSE930UC
7921A5TRSU	2LA-HSL922U	7938CTRSU	5S-2LA-HSE926U
-	2LA-HSL926UAD	7002A5TRSU	5S-2LA-HSE922UAD

5 Keys to Choosing the Right Bearing - Selection Guide | DXP Jul 23, 2019 — 1. Load Bearing load is measured in several ways. · 2. Speed Every bearing is designed to operate well within a certain speed range. · 3Loads and selecting bearing size | SKF | SKF Loads and selecting bearing size for high temperature bearings and bearing units. The bearing size is selected based on the basic static load rating C0 (data

Bearing Selector Guide | AST Bearings Below, you can quickly select the bearing or related product that is just right for your application. To start, expand the product section below (click on the "+" sign) 5. SELECTION OF BEARING SIZE When selecting a bearing based on the basic load rating, it is best to choose an a1 reliability factor appropriate for the projected use and an empirically